

## APPLICATION GUIDE

# EuroProt+ Operating Manual with Troubleshooting Guide

## FW version 2.10



DOCUMENT ID: PP-13-22720  
VERSION: 1.2  
2023-09-19, BUDAPEST

PROTECTION, AUTOMATION AND  
CONTROL FOR POWER INDUSTRY



## VERSION INFORMATION

VERSION	DATE	MODIFICATION	COMPILED BY
1.0	2023-03-14	First published version	Saina, Zsarnai
1.1	2023-03-29	Minor corrections	Saina
1.2	2023-09-19	Events, disturbance recorder non-volatile info added	Erdős

## CONTENTS

1	Introduction .....	6
2	Starting the device .....	6
2.1	The hardware modules of the device .....	6
2.2	Fast startup.....	6
3	Local operation on the front panel .....	7
3.1	The structure of the human-machine interface of the device .....	8
3.2	Using the touch buttons.....	9
3.3	Using the HMI touchscreen buttons .....	11
3.3.1	The home screen.....	11
3.3.2	The parameters menu .....	12
3.3.3	On-line functions, Events, System settings .....	14
3.3.4	User-defined/Custom screens.....	14
4	Remote operation via web browser .....	16
4.1	Properties of the Ethernet communication .....	16
4.1.1	The Ethernet connection .....	16
4.1.1.1	Using the RJ-45 connection .....	16
4.1.1.2	Using the EOB connection .....	17
4.1.1.3	Using fiber optic connections.....	17
4.1.2	Settings needed for the Ethernet connection .....	17
4.1.2.1	Connection to the device with fix IP address.....	17
4.1.3	Using web browsers .....	19
4.2	Menu items in the web browser.....	20
4.2.1	Main panel .....	20
4.2.2	Parameters .....	21
4.2.2.1	Managing multiple parameter sets .....	23
4.2.3	System settings .....	24
4.2.4	Online data .....	25
4.2.5	Events.....	26
4.2.6	Disturbance recorder .....	27
4.2.7	Commands .....	30
4.2.8	Network protectionHood.....	31
4.2.9	Documentation .....	32
4.2.10	Security.....	32
4.2.10.1	Security settings .....	32
4.2.10.2	User manager.....	33
4.2.10.3	Certificate handling.....	34
4.2.10.4	Alarms / Logging.....	35
4.2.10.5	Audit trails .....	36
4.2.11	Advanced.....	37
	Maintenance .....	37
4.2.11.1	.....	37

4.2.11.2	I/O tester .....	40
4.2.11.3	Update manager .....	42
5	Troubleshooting .....	44
5.1	Warning and Error Messages.....	44
5.1.1	Warning messages in the web browser .....	44
5.1.2	Error messages in the web browser .....	48
5.1.3	Error messages on the LCD screen .....	51
5.1.4	Operation of the IFR (Internal Fault Relay) .....	53
5.2	Necessary data before contacting Protecta Support.....	53
5.2.1	Serial Number of the Device .....	53
5.2.2	Information about firmware and configuration versions .....	54
5.3	Quick Troubleshooting .....	55

## USED SYMBOLS



Additional information



Useful information for settings.



Important part for proper usage.

## 1 Introduction

The **EuroProt+** type complex protection in respect of hardware and software is a modular device. The modules are assembled and configured according to the requirements, and then the software determines the functions. This manual describes the common properties of the numerous possibilities. It also provides technical guidance to operate the device locally with the LCD and remotely with a web browser. The individual characteristics of the specific applications are described in the manuals of the factory configurations.

## 2 Starting the device

In order to meet the device at the first time, this chapter provides information for new users to secure a safe first start-up of the device.

### 2.1 The hardware modules of the device

For technical details of the modules of the **EuroProt+** type complex protection please see the document “**Hardware description**”. The applied modules for a certain application are listed in the corresponding “**Configuration description**” document. These documents are available on-line on the Protecta website by selecting the desired product.

### 2.2 Fast startup

The CPU module of the device is equipped with two processors: RDSP, for protection function processing, and CDSP, for communication function processing.

After powering up the device, the RDSP processor starts-up with the previously saved configuration and parameters. Generally, the power-up procedure for the RDSP and application functions takes approx. 4-5 sec. During this time the “Status LED” (see Figure 3-1) is red. If the protection functions are ready for operation the red LED turns to green, the fault relay NO contact closes (3-4 or 5-6) and the device is ready to trip after this short period. During the restart procedure after a new downloaded configuration, the LED is also red for a short time. Latched red LED however means general error. In this case the protection functions are not available.

The CDSP’s start-up procedure is longer, because its operating system needs time to build its file system, initializing user applications such as HMI functions and IEC61850 software stack. The availability of the touch screen of the front panel after about 25-30 seconds indicates successful termination of the start-up procedure.

### 3 Local operation on the front panel




Figure 3-1 The front panel of the device

### 3.1 The structure of the human-machine interface of the device

The EuroProt+ device HMI on the front panel contains the following elements:

Table 3-1 The elements of the front panel

FUNCTION	DESCRIPTION
User LEDs (16 pcs)	Three-colors, 3mm circular LEDs programmable by the user.
COM LED (1 pc)	Yellow, 3mm circular LED indicating front panel communication link and activity
Touch button LEDs (4 pcs)	Yellow, 3mm circular LEDs indicating touch button actions
Status LED (1 pc)	Three-color, 3mm circular LED Green: normal device operation Yellow: device is in warning state Red: device is in alarm state
Touch buttons (4 pcs)	HMI touch buttons (On/Off Operation, Change Screen, LED acknowledgement), see Paragraph 3.2 for details.
Buzzer	Audible touch button pressure feedback
Changeable LED description label	Describes user LED functionality
3.5" or optional 5.7" display	320*240 pixels TFT display with resistive touch screen interface
Optical interface	This interface is made for EOB connection, and/or serves as a service port for Protecta personnel only.
RJ-45 connector	Supporting 10/100Base-T Ethernet connection
EOB connector (option)	<b>Ethernet Over Board:</b> communication interface realizes isolated, non-galvanic Ethernet connection with the help of a magnetically attached EOB device. This is a proprietary and patented solution from Protecta Ltd. <b>EOB1:</b> Supporting 10Base-T Ethernet connection. Passive device with one RJ45 type connector. <u>Obsolete module.</u> <b>EOB2:</b> Supporting 10/100Base-Tx Ethernet connection. An active device that has a USB port in addition to the RJ45 connector for powering up. <u>All EOB topics in this manual are referring to EOB2.</u>



### 3.2 Using the touch buttons

The home screen of the local LCD together with the red marked “Change screen button” and the “Operation buttons” is shown in the picture below.



Figure 3-2 The device face showing the home screen

**Change screen button** - This hardware button changes the currently displayed screen for the subsequent one. The available screens and the order in which they appear by default are: the home screen, parameters, online functions, events, system settings, security settings and the custom screens which can be added by the user with the help of the EuroCAP software. The order can be changed in the LCD editor of the EuroCAP configuration tool. When pressing the “**Change screen button**” – as an example – the windows shown in Figure 3-3 below can be seen and applied one-by-one, cyclically.




Figure 3-3 Default menu screens (excluding the home screen) displayed on the LCD

Touch the navigation icons or the displayed text lines to perform any actions via the LCD screen.

**Operation buttons** - These buttons can be used to define certain functions on customer-defined windows. For example, the user can set up these buttons to turn on/off a circuit breaker or increment/decrement the position of the tap changer of a transformer. For more information, please refer to the User-defined/Custom screen section.

**LED reset button** – Pressing this button removes the latches from all active LEDs and resets them. Apart from an LED reset, this button can also perform other tasks depending on the relay configuration. Use of this button, as well as other HMI buttons can be changed using EuroCAP configuration tool by programming the outputs of the *HMI buttons* function block from the logic editor. For more details, see the respective manuals.

### 3.3 Using the HMI touchscreen buttons

The touchscreen is the main control area where the user will enable functions and input values by touching the screen. The touchscreen can be also remotely accessed and controlled through the web interface (for more information see the corresponding sections in the remote user interface).

#### 3.3.1 The home screen



**Lock icon** – Touching this icon unlocks the device LCD interface, allowing a user to access various menu items in the device with specific privileges e.g. view settings, view data, manage settings, etc.




Figure 3-4 Unlocking the device LCD, notice the change in the “lock” icon

**NOTE:** The device is initially configured with the “Guest” user with all the privileges. As a result the user doesn’t need to unlock the screen to access all the functions. However, if the “Guest” rights are limited, the user will need to unlock the screen by logging in in order to access some privileges.

The device is also initially configured with an “Admin” user with a default password **C1b3rS3cl**. Unlock the device with these credentials if the accessibility of the device is limited. See paragraph 4.2.10.2 for more details on user management.

**Default/secondary languages (optional)** - If available, the user can change the language of the device by pressing the corresponding flag. With this, the language will change (provided that the translations exist) on the following objects:

- remote web interface
- all menu points
- newly generated events
- newly created disturbance records
- device messages (e.g. command confirmation)



**NOTE:** if the language is changed by using the button on the web interface (see Paragraph 4.2.1), it will change on the web interface only; the other parts from the list above will remain as they were set here.

**Information and LED buttons** – By pressing the “i” button located on the top right corner of the home screen, additional information is displayed as shown in Figure 3-5. The LED icon on the top left corner starts the front panel LED test (see Paragraph 4.2.11.2).



Figure 3-5 Additional information on the home screen

### 3.3.2 The parameters menu

In this screen, the user can view, set and edit certain parameters within the device. The user can also choose which parameter set the device should use; this is done with the “Activate” button. The currently active parameter set has a red box around it (first set in the picture below).

In order to edit or activate a parameter set, touch its name first to select it: it will be highlighted in blue. Then touch the "Edit" or "Activate" button accordingly.




Figure 3-6 Parameter sets

**Activate button** - Activates the selected parameter set so the device will use those values. The activated parameter set will have a red box around it. Only devices configured with multiple parameter sets have an activate button.

**NOTE:** if the parameterset change has a condition configured to it, the activation button will disappear. In this case, activation of the parameter sets is defined in the device configuration (e.g. binary input or software switch).

**Edit button** - This button takes the user to another screen listing the available function blocks (FBs).

The screen in Figure 3-6 will only appear if there are more than one parameter sets. Otherwise, the user is immediately taken to the function blocks. Normally, the various function blocks appear in blue. In case someone has changed a certain value within a given function block, the name of the function block in this menu item will turn red to notify the user. Within function blocks, the values of the parameters are normally green, but if they have been modified, they will also turn red. As an example, change the VT4 voltage type from 200V to 100V as follows:




Figure 3-7 Changing VT4 module Type



**IMPORTANT!** In order to finalize all changes, the user has to go back to the screen where all the function blocks are listed and save the changes as shown above.

Also, make sure that while someone is modifying the parameters in the LCD touchscreen, no one else is doing so on the web interface since this could lead to confusion as to what the values of a parameter set are.

Other parameters can be modified similarly to the previously described VT4 voltage type. The following parameter types are available in the function blocks:

**Integer or timer** - This is a whole number, and it can be entered with the help of the number pad.

**Floating-point number** - This is a number that has a decimal point. This can also be input through the number pad.

**List item** - A list is displayed with all the possible choices. In this case the user simply needs to select the desired one (e.g. VT4 voltage type).

**Checkbox** - The user has the option of enabling or disabling the parameter.

### 3.3.3 On-line functions, Events, System settings

These menu items have the same content as described in chapter 4. System settings can be modified similarly to the parameters in paragraph 3.3.2.

### 3.3.4 User-defined/Custom screens

It is possible to add screens based on the user's needs with the help of the EuroCAP software. The operation buttons can also be set up to perform certain functions. An example can be seen using a Single Line Diagram on the following page.

Consider a network represented by the SLD below and we have set up the required operational buttons to function as "on"/"off". To switch "on" the busbar disconnector Q1:

1. Touch the disconnector "Q1" icon on the touchscreen.
2. The selected object is highlighted and starts blinking. Some action must be performed with the chosen object; otherwise the selection times out after a short period.
3. So, while blinking, press the "I" button, which has been configured to be the "on" button when the Q1 object is highlighted.
4. A dialogue box pops up for confirmation of this operation. Again, a limited time is available for confirmation, otherwise the requested operation is canceled. Press "Ok" to confirm.
5. Another dialogue box pops up stating that the operation was successful. Press "Ok".
6. The scheme is updated accordingly, with the Q1 line disconnector in the "on" position.

Note again that this behavior was only an example; it may vary according to the configuration of the actual device.




Figure 3-8 Closing Q1 disconnector

This screen is updated in real time. A change in any sort of state or any parameter that is set up to be measured, will be shown and updated accordingly.

If there is an error with the operation (e.g. block by interlocking), the device will notify the user with another another dialogue box popping up with the reason for the error.

## 4 Remote operation via web browser

A web browser and an Ethernet connection are needed in order to access the device interface. HTML5 compatible web browser is recommended. To properly display the data on the screen, it is recommended to have a screen resolution of at least 1024x768. The latest version of the following web browsers can be used:

- Mozilla Firefox
- Apple Safari
- Google Chrome
- Microsoft Edge

JavaScript must also be enabled in your browser. For security reasons, the device allows only limited number of connections over the network (a maximum of 10 is guaranteed).

### 4.1 Properties of the Ethernet communication

The built-in 5-port Ethernet switch allows EuroProt+ to be connected to IP/Ethernet based networks. The following Ethernet ports are available in general:

On the front panel of the device:

- RJ-45 Ethernet or EOB (Ethernet over Board) user interface

On the rear side of the CPU unit:

- Station Bus (100Base-FX Ethernet)
- Redundant Station Bus which can be:
  - 100Base-FX Ethernet, or
  - 10/100Base-T port via RJ-45 (only one can be active of these two)
- Process bus (100Base-FX Ethernet)

The different HMI and CPU types are utilizing different ports. Further information about the available ports and the applied interfaces on various HMI and CPU types can be found in the “**Hardware description**” document.

The embedded web-server supports the following actions:

- Modifying user parameters
- Managing the event list and disturbance records
- Managing passwords
- Online displaying measured data and generated binary information
- Performing commands
- Firmware update
- Performing other administrative tasks
- User management and security settings

#### 4.1.1 The Ethernet connection

There are several ways to be connected to an Ethernet network. The availability of the below listed connection types depends on the device hardware configuration.

##### 4.1.1.1 Using the RJ-45 connection

RJ-45 connector is available on the front panel if no EOB is selected for the configuration. In addition, many CPU types also utilize an RJ-45 connector, which is located on the rear side of the device on the CPU card. Using an UTP cable with RJ-45 connector at both ends, the device can be connected directly to a computer or an ethernet switch.



#### 4.1.1.2 Using the EOB connection

EOB connection is available on the front panel if no RJ-45 connector is selected for the configuration. Attach the magnetic EOB connector to the front panel of the device (see Figure 3-1). The magnets assure the correct position of the adapter. Connect the other two ends of the cable to the RJ-45 connector and to the USB port of a computer. The special cable with magnetic connector on one end and RJ-45+USB connectors on the other end shall be ordered from Protecta.

#### 4.1.1.3 Using fiber optic connections

The different types of fiber optic interfaces for 100Base-FX Ethernet provides connection to an Ethernet switch with identical fiber optic inputs. Using this connections all IED-s on the network with client functionalities, e.g. a computer, has access to the device. For more details about the fiber optic connector types see the CPU and COM module sections in the **“Hardware description”**.

### 4.1.2 Settings needed for the Ethernet connection

The web interface of the EuroProt+ devices can be accessed over Ethernet based protocols only. Therefore, it is extremely important to set up the network before accessing the device.

Typically, the rear ports are connected to the substation network. The front port is ideal for management or troubleshooting. Station bus settings and front ethernet settings can be defined separately.

To connect the device to a station or corporate network, contact the system administrator for available IP address, gateway address, net-mask, DNS and NTP server addresses.

The user can also connect directly to the device via Ethernet protocol. In the following guidance, we assume that the user connects directly to the device via computer without the presence of any active network component (e.g.: switch, router).

#### 4.1.2.1 Connection to the device with fix IP address

The device uses fix IPv4 address range and the user is allowed to modify the address. User's computer must be set with fix IP address and netmask according to the used IP address range and netmask in the device.

##### Settings of the device:

The initial IP addresses of the device can be read from the home page of the LCD. If connected via the rear ports, use the displayed “IP address”. If connected via the front ethernet port, use the displayed “FE IP address”. The default netmask for the rear IP address is 255.255.0.0 while for the front IP address is 255.255.255.0.

After the initial setup, the IP address settings can be changed from the **System settings** -> **Station bus settings** menu for the rear ports and **System settings** -> **Front ethernet settings** for the front port.

The screenshot below shows sample **Station bus settings**:



	Device value	New value
IP address	192.168.80.11	192.168.80.11
Netmask	255.255.0.0	255.255.0.0
Default gateway	192.168.1.1	192.168.1.1
IP address mode	Static IP	Static IP
DNS1 address	192.168.1.1	192.168.1.1
DNS2 address	0.0.0.0	0.0.0.0
Redundancy mode	PRP	PRP

Figure 4-1 Sample station bus settings in the device

Sample **Front ethernet settings** are shown below:

	Device value	New value
Mode	Separate	Separate
VLAN Id	4094	4094 (1 - 4094 / 1)
IP address	10.200.200.1	10.200.200.1
Netmask	255.255.255.0	255.255.255.0
Internal network access	<input type="checkbox"/>	<input type="checkbox"/>
DHCP server	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Figure 4-2 Sample front ethernet settings in the device



**NOTE:** This illustration assumes that the front ethernet is “Separated” from the station bus. Otherwise, same IP settings as the station bus settings are used.

**Settings of the user's computer (with fix IP address):**

- **Connection to the station bus**

The possible IP settings of the user’s computer according to the sample device settings above:

*IP address:* in range from 192.168.0.1 to 192.168.254.254\*

*Netmask:* 255.255.0.0

*Default gateway:*192.168.0.1

*\*Note: the IP address must differ from that of the device*

Figure 4-3 An example of settings in the user’s computer with fix IP address

- **Connection to the front ethernet**



The front ethernet port has an embedded DHCP server. To connect the PC, enable DHCP by checking the “DHCP server” box under the **Front ethernet settings** tab as shown in Figure 4-2 above. Secondly, use automatic IP settings in the PC network settings. See Figure 4-4 below.




Figure 4-4 Possible settings in the user’s computer with DHCP server



**IMPORTANT:** Caution should be taken if the front ethernet port has to be connected to the corporate network. In these cases, as a safe practice, uncheck the “DHCP server” box in the **Front ethernet settings** tab, otherwise the device could act as a new DHCP server in the network.

### 4.1.3 Using web browsers

First the user must check if the browser is accessing the device via proxy-server. If there is a proxy-server in the network, the system administrator shall be contacted in order to get access.

If this is clarified, the user can type the IP address of the device into the browser’s address bar. (The IP address can be read from the home screen of the local LCD). After that the usual procedures of web browsing shall be followed.

## 4.2 Menu items in the web browser

### 4.2.1 Main panel




Figure 4-5 Main menu

The front panel of the device can be controlled from here (Figure 4-5). The image in the center of the screen acts/responds in the same way as the touch screen and the LEDs, except the on (1) and the off (0) buttons. These two buttons are inactive for security reasons.

The X button on the bottom of the front panel picture initiates a LED reset. LED description text is determined by the configuration and may be different than the actual label inserted in the device front panel.

**Identification** - User can change the station and device names from this panel by typing in the new values and clicking on the Rename button. IEC61850 IED name is only for display here but can be edited in the EuroCAP tool if needed.

**Information part** - There are two fields for measuring device operating time. Uptime field displays the time elapsed from the last power on of the device. Device lifetime field value equals the number of days of the device's energized state. In case of a CDSP update, the device uptime disappears and RDSP/CDSP uptime appear.

The language button (if present) under the menus changes the displayed language on the webpage only. This means that the menus (parameters, settings etc.) will be shown in the chosen language, but the events and disturbance records will still be generated on the language set on the main local LCD screen (see Paragraph 3.3.1 for details)

## 4.2.2 Parameters

Various parameters and variables can be viewed and changed in this menu item. The user can manage different parameter sets with the ability to set, rename, export and import them. A password can be applied for the import, export and set settings options. All parameters are part of a certain function block which can be individually opened or closed using the **[+]** or **[-]** symbol. Parameter values are displayed and can be modified in text fields, list boxes or check boxes.

	Device value (Par set 1)	New value	
Range	Type 100	Type 100	
Connection U1-3	Ph-N	Ph-N	
Connection U4	Ph-Ph	Ph-Ph	
Direction U1-3	Normal	Normal	
Direction U4	Normal	Normal	
VT correction	100	100	% (100 - 115 / 1)
Rated Primary U1-3	100.00	100	kV (1.00 - 1000.00 / 0.01)
Rated Primary U4	100.00	100	kV (1.00 - 1000.00 / 0.01)

Figure 4-6 Parameter settings

Buttons on the top of the parameter's sheet provide fast expanding and collapsing all the function panels and make finding a parameter easy. Print button generates a printer-friendly layout opened in a new browser window.

General layout of the parameter's sheet consists of columns:

*The first column* contains the name of the parameter, this text comes from the configuration of the device.

*Second column* displays the current values of the selected parameter set stored in the device. The parameter set can be chosen from the combo-box of the main menu (see Figure 4-7). Changing the parameter set here doesn't mean activating it, only loading to the fields. You can find more information on activation in this chapter later.

*Third column* is used by the user to enter the desired settings. The expected value range and step are shown on the right side of the parameter column.

Changing any setting in the third column will be marked with **blue function block name** and with **blue text** in the corresponding line of the first column.

The detailed description of fields are as follows:

**Textfield** - Text fields hold values that can be modified. To prevent invalid values from being loaded into the device, make sure that all values entered are within proper range. In case a wrong value is entered, the user will be alerted and the value is reset to the last correct value.

**Listbox** - By clicking on the list box, the user can choose from the available values listed within the box. (The list box represents enumerated type parameters.)

**Checkbox** - The user can enable or disable certain functions and properties with the check box, by clicking on the box. If the checkbox is ticked, the parameter is enabled. In contrast, if the check box is empty, the parameter is disabled. (The check box represents boolean or binary type parameters.)

**Unit** - This displays the unit of parameter where applicable. Not all parameters have units.

**Range/Step** - This applies only to text fields; it displays the range a value can take. The step value represents the amount by which the value can be incremented/decremented. For example, if a parameter has a default value of 100 with a range of 1-1000 and a step value of .01, its value can be changed to 99.99, or 99.98, or 99.9, or 99 or 100.01, or 100.02, or 100.1, or 101, and so on. The value cannot go below 1.00 or above 1000.00, since that would be out of range. As another example, if the same parameter had a step value of 5, then we could only change the default value of 100 to 95, or 105, and so on.




Figure 4-7 Main menu view with and without multiple parameter sets

Modified parameter values can be written into the selected parameter set by clicking “Set parameters” button on the main menu panel. In case of a device with only one parameter set there is no parameter set selector combo-box, as it can be seen on the right side of Figure 4-7.

Values are checked for change before the user navigates away from the actual page or another parameter set is being loaded. By pressing Cancel, the browser will remain on the actual page. By pressing OK, the browser will ignore the changes made and navigates away to the page selected.




Figure 4-8 Unsaved data when leaving the page

### 4.2.2.1 Managing multiple parameter sets

Towards the bottom of the page there are options to manage parameter sets. These buttons and functions only appear if the device is configured to have more than one parameter set. The following buttons are available:




Figure 4-9 Parameter set control field

**Rename** - This renames the selected parameter set after the user types in a desired name in the text field. Make sure that you use alphanumeric characters, spaces, dashes, or underscores as input and that no another set has the same name.

**Save parameters** - Corresponding parameter set can be saved as a \*.par file.

**Activate** - This enables to activate the parameter set that in line with the button so the device will use the values from that specific set. This button only appears, if there is more than one parameter set and there are no other specified conditions in the configuration for activating the parameter set. The active parameter set name will be displayed in green.

**NOTE:** Activating a parameter set doesn't load the values to the edit fields above. Parameter set values can be loaded into the editable fields by using the combo-box placed on the left side of the main menu panel (see Figure 4-7) or by clicking on the Load to editor button.

**Load to editor** - This will load the parameter set in line with the button in the editable fields.

**Reset to defaults** - This resets the values on screen with the factory default settings.

**Load parameters** - This loads a previously saved parameter file and sets the values on the screen based on its contents.

### 4.2.3 System settings

In this menu item, some adjustments can be made to general device settings. The text fields, list boxes, and check boxes are almost the same as in the **Parameters** menu item except for one type of text field, the IP address field, which is found only here in the system settings menu item.




Figure 4-10 System settings menu

The behavior of the **System settings** menu is very similar to the **Parameters** menu. Brief explanations of each item in the **System settings** menu are available below:

**System parameters** – This field is used for power system frequency setting.

**Station bus settings** – This field includes settings for the Ipv4 based communication like IP address, IP address mode, redundancy mode, mask, gateway, and DNS addresses.

**Front ethernet settings** – The front ethernet settings field is used to define the settings related to the ethernet port on the front panel of the device. Mode, Ipv4 address and netmask, VLAN settings can be keyed in here. Once again, caution is advised in the use of the DHCP server setting here. Refer to paragraph 4.1.2.1 for more information.

**Ethernet communication** – The device can communicate using several Ethernet based protocols at the same time. Only the IEC61850 communication is licensed, all the other protocols are available by default.

**Serial communication** – Only one protocol can be selected for serial communication purposes, physical parameters can be set in this field. Note that serial communication needs appropriate CPU card.

**Time synchronization** – The device handles broad range of time synchronization protocols: NTP server (SNTP), serial communication, and different pulse inputs. If Time sync. Warning parameter is enabled and the device is not synchronized, an alarm is raised (status LED goes yellow).

**Time zone settings** – Use this field to set the offset to the GMT time and the settings of daylight saving.

**LCD backlight** – Parameters in this field control the behavior of the LCD panel. Backlight will switch off after its timeout. The Backlight group is useful if you have more than one device close to each other. Touching one of them will switch on the LCD screen of all devices that belong to the same group.

More information about a particular setting can be obtained by hovering over the helptext question mark in the setting row.



### 4.2.4 Online data

This displays data measured by the device. The values on the screen are updated in every second. All data on this page is read-only, therefore they cannot be modified. In case there is a counter on the page, there will be a button next to it, which will reset it.




Figure 4-11 Online sheet

Binary data are displayed as checkbox, enumerated data will be presented as text information. If user has HTML5 compatible Internet browser, certain analogue measurements will be drawn as vectors.

## 4.2.5 Events

The **Events** menu displays the internal event list of the device. Every event is listed with time stamp, function block title, event type and event status. Time resolution is 1 ms, the device can contain approximately 10000 events in its non-volatile memory. If the list grows larger than this, the oldest events are erased.

If the mouse cursor hovers over a function block title for a short time, all event entries that belong to the same function block are highlighted in bold. Also, if the cursor is over an event type, all events of the same type will be highlighted (Figure 4-12).

The **Events** page is not refreshed automatically, the user can refresh it by clicking on the Refresh button.

Erasing all events and exporting them to a text file is also possible.

An **Event filter** can be utilized according to user's needs: there are filters for event row number, date and contained text, see rightmost part of the picture.

The screenshot displays the 'Events' page interface. At the top, there are buttons for 'Refresh', 'Erase all events', and 'Export to file'. Below these is the 'EVENT LIST' table. The table has the following columns: Ordinal, Timestamp, Function block title, Event type, and Event Status. Red arrows point to these columns with labels: 'Timestamp', 'Function block title', 'Event type', and 'Event Status'. The table contains 32 rows of event data, including entries like 'Distance protection', 'Trip Logic', and 'General Trip'. To the right of the table is the 'EVENT FILTER' panel, which includes fields for 'Ordinal', 'Date' (with a date picker), and 'Contains', along with '+' and '-' buttons and a 'Reset' button. The 'PROTECTA HUNGARY' logo is located in the bottom right corner of the interface.

Figure 4-12 Sample event list

## 4.2.6 Disturbance recorder

The **Disturbance recorder** (Figure 4-13) page allows the user to download or view the recorded disturbances. Every record is stored in COMTRADE format in the device's non-volatile memory and can be downloaded in a zipped file (with CFG, INF and DAT files inside). The displayed recording time information is used as a reference to the stored records. Records can be downloaded individually or as a batch. By clicking the "Download all" button, all records will be downloaded into one compressed (.zip) folder.

**NOTE:** The disturbance recorder function has a limited storage capacity, after which the records are overwritten on a FIFO basis.

Date of record	Download	View	Erase
2022.08.18 15:04:08.956 (145 kBytes)	Download	View	Erase
2022.08.18 15:04:19.286 (145 kBytes)	Download	View	Erase
2022.08.18 15:05:35.235 (145 kBytes)	Download	View	Erase
2022.08.18 15:12:39.836 (150 kBytes)	Download	View	Erase
2022.08.18 15:12:46.576 (150 kBytes)	Download	View	Erase
2022.08.18 15:12:53.356 (150 kBytes)	Download	View	Erase
2022.08.18 15:13:40.576 (150 kBytes)	Download	View	Erase
2022.08.18 15:23:31.677 (150 kBytes)	Download	View	Erase
2022.08.18 15:23:38.417 (150 kBytes)	Download	View	Erase
2022.08.18 15:23:45.236 (150 kBytes)	Download	View	Erase
2022.08.18 15:24:32.847 (150 kBytes)	Download	View	Erase
2022.08.19 09:56:33.086 (143 kBytes)	Download	View	Erase

Figure 4-13 The disturbance recorder page

A simple built-in preview function makes work easier (Figure 4-14 to Figure 4-17). This previewer allows for a quick evaluation of the disturbance. Both analogue and binary channels are displayed on the screen.

On the right side there is a floating panel with buttons to control the behavior of the display. Buttons with plus and minus sign are used for adjusting the horizontal zoom of the picture. Clicking on the "1:1" button resets the view to the default horizontal size. Scale mode is a toggle button to change the way of the analogue channel drawing. By default, it is drawn using a common vertical scale calculated from all available analogue channels with the same unit parameter. In other words, it uses a grouping of the channels according to their unit. If the user clicks on this button, every analogue channel will be drawn with its individual scale calculated from the maximal value of that channel.

Time evaluation is possible by placing markers on the time functions of the recorded disturbances. Upon opening a record preview file,

1. A permanent marker along the time domain indicates the trigger time of the disturbance.
2. A hovering marker indicates the post-trigger time.
3. The marker could also indicate the pre-trigger time by hovering over the reverse side of the permanent marker.
4. By clicking anywhere along the record, the time stamp is removed from the permanent marker and placed on the newly-clicked position. After this, again, a hovering marker (similar to the pre-trigger/ post-trigger duration) displays the time window.




Figure 4-14 Record preview – analogue channels showing post-trigger time




Figure 4-15 Record preview – pre-trigger time




Figure 4-16 Shifted time-stamp




Figure 4-17 Disturbance record's binary channels

## 4.2.7 Commands

The device may contain function blocks with controllable objects whose commands appear on this page. A command can be issued by clicking the appropriate button on the field of the function. A confirmation dialog will ask the user to confirm the command (Figure 4-19).




Figure 4-18 Command sheet




Figure 4-19 Confirmation dialog

The mode of device defined in the **Common** function block has 5 setting options based on IEC61850-7-410 definition; these commands are present in all EuroProt+ devices:

- “On” mode is meant for the normal operation of the device, where all the inputs are received, displayed, processed, outputs generated, and events reported to client.
- In “Blocked” mode, the inputs are received, displayed, but are not processed. No outputs are generated, nor events reported to client.
- In “Test” mode, all inputs are received, displayed, processed, outputs generated, but the events are flagged as “test” as they are reported to client.
- The “Test/Blocked” mode enables the device to receive, display and process the inputs. Like in test mode, event reporting is flagged as “test”. The device does not generate any outputs. The outputs are blocked.
- In “Off” mode, the inputs are received but not displayed, not processed, no outputs are generated, no events are generated.

The table below summarizes the operation of each mode as specified by the standard.

Table 4-1 Mode of operation commands

MODE OF DEVICE:	ON	BLOCKED	TEST	TEST/ BLOCKED	OFF
Function	active	active	active	active	not active
Outputs (to process)	generated	not generated	generated	not generated	not generated
Reporting (to client)	yes	no reporting	flagged as test	flagged as test	no reporting
Control services (from client)	accepted	rejected	accepted	accepted	rejected
Functional (process related) data	visible	visible	visible	visible	not visible

## 4.2.8 Network protectionHood

This menu shows devices that are located on the same network as the device. Compatible devices are identified and information is displayed about them. The currently accessed device is highlighted in red. By clicking on the other links, the user will be redirected to the corresponding device.

The screenshot shows the 'Network ProtectionHood' web interface. On the left is a navigation menu with options like 'Main', 'Parameters', 'System settings', 'Online data', 'Events', 'Disturbance recorder', 'Commands', 'Network protectionHood', 'Documentation', 'Security', 'Advanced', 'Logout', 'Active Security Alarm', 'User: admin', 'Role: Full Access', '04:27:10', and 'Change Password'. The main area displays a table titled '[-] DEVICES FOUND ON THE NETWORK'. The table has columns: Health, IP Address, Platform, Station name, Device name, Version, Functionality, RDSP/Xilinx, CDSPP rev., and Station bus MAC. The table lists various devices with their respective details, including IP addresses, platform types (EuroProt+), station names, device names, versions, functionalities, and MAC addresses. A 'Refresh' button is located at the bottom of the table.

Figure 4-20 Network protectionHood

## 4.2.9 Documentation

This panel displays the embedded and custom files uploaded to the built-in storage unit of the device. The **User documents** section allows the user to upload any type of documents and files, which will be saved on the device and will be accessible for later use. There is an 8 MB limit available, single file size maximum is 2 MB.

**Embedded documents** on the other hand, are uploaded by the manufacturer during equipment manufacture. The user cannot alter or delete them, but can read them.




Figure 4-21 User documentation

## 4.2.10 Security

The purpose of this menu is to allow the user to modify all security related settings in the device. A brief explanation of each menu item will be given in the subsections that follow.

### 4.2.10.1 Security settings

**Secure handling** – secure handling settings allow the user to manage between convenience and security of the device. Settings such as enabling/disabling the LCD confirmation dialogue upon loading of settings, enabling/disabling the operation of the device HMI interface from the web, enabling/disabling LCD mirroring can be found here.

**System services** – Use this field to set the web interface mode, enable secure file transfer mode, discover devices on the local network, set up remote login feature and log server.

**Client whitelist** – If this function is enabled, only the allowed clients can access the device in the selected role i.e. SCADA, Management, or both.

If an IP address is whitelisted for the SCADA role, this means that the IP address will only be allowed to access the device from SCADA only (i.e. IEC 61850, IEC 101/104, Modbus, etc.), access via web browser or EuroCAP is not permitted. Similarly, if an IP address is whitelisted for Management role, the IP address is only allowed access to the device from the web browser or EuroCAP, access via SCADA is not permitted. Whitelisting for both roles is also possible.






Figure 4-22 Security settings menu

### 4.2.10.2 User manager

Not just any person can access the webpage functionality of the device. Users must be authenticated. Before the device is commissioned for use, a full user management setup is recommended to be completed. This menu is used for this purpose.

**Users** – Here, the names and roles of the personnel allowed to operate the device can be added, edited or deleted.

**Roles** – Here, the role rights management can be viewed. With a CyberProtect licence, the rights of the standard roles can be modified, while new roles can be added.

**LDAP authentication, authorization** – Apart from local IED device authentication, the device also allows for central server authentication. This menu is used to manage the settings of this type of authentication. This option is only available with a CyberProtect license.

**Session handling** – The settings related to the management of clients' sessions with the device can be managed here. These include parameters such as session timeout, maximum number of sessions, maximum number of users, etc. This is also recommended to be done before device commissioning.

**Import / Export** – If there are more than one EuroProt+ devices being managed by the same people, users in one device can also be authorized in the other. This menu allows for uploading an encrypted authentication file from another device. If this is done, the same users in one device can be found in the other.

**NOTE:** Initially, the user is allowed full access to the device through the “Guest” user. It’s highly recommended that the “Guest” user rights be limited before the device is commissioned for use. Additionally, the device is configured with an “admin” user with default password **C1b3rS3c!**. During the system security setup, it is also recommended that the “Admin” user be deleted or the password changed.




Figure 4-23 User manager menu

### 4.2.10.3 Certificate handling

In this menu, HTTPS and IEC 61850 security certificates can be uploaded. Please contact your system administrator for the proper settings.

**HTTPS Certificate** – This is an option for uploading a server’s certificate, which has been signed by a publicly trusted certificate authority (CA). Therefore, the browser can accept that any identifying information included in the certificate has been validated by a trusted third party.

**IEC 61850 TLS Configuration** – The requisite parameters and certificates for securing IEC 61850 communication can be uploaded here.




Figure 4-24 Certificate handling menu

#### 4.2.10.4 Alarms / Logging

This menu contains the settings for alarms generated by the device; and the settings for the level of system log events.

**Entries** – Alarms/alerts from device with all the relevant details e.g. facility, severity, time etc. are automatically logged here.

The screenshot shows the 'Alarms / Logging' interface with a list of entries. The left sidebar contains navigation options like Main, Parameters, System settings, Online data, Events, Disturbance recorder, Commands, Network protection/food, Documentation, Security, Security settings, User manager, Certificate handling, Alarms / Logging (selected), Audit trails, Advanced, and Logout. The main area shows a table of entries with columns: Id, Facility, Severity, Time, User, Source, Destination, Activity, Details, and Remove.

Id	Facility	Severity	Time	User	Source	Destination	Activity	Details	Remove
730	User	Notice	2022-06-09 06:25:59			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
739	User	Notice	2022-06-09 16:06:59			192.168.10.11	Startup	Device started	Dismiss
740	Daemon	Notice	2022-06-09 16:07:17			192.168.10.11	Card	A card is missing or has a mismatch	Dismiss
760	User	Notice	2022-06-09 16:19:58			192.168.10.11	Startup	Device started	Dismiss
764	User	Notice	2022-06-09 16:23:22			192.168.10.11	Startup	Device started	Dismiss
778	User	Notice	2022-06-09 16:45:55			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
784	User	Notice	2022-06-09 18:25:21			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
786	User	Notice	2022-06-09 18:39:08			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
789	User	Notice	2022-06-10 08:41:44	admin	192.168.4.121	192.168.10.11	Options	Restart of RDSP is requested	Dismiss
790	User	Notice	2022-06-10 08:43:27			192.168.10.11	Startup	Device started	Dismiss
796	User	Notice	2022-06-14 14:24:44			192.168.10.11	Startup	Device started	Dismiss
797	User	Notice	2022-06-14 14:25:15			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
799	User	Notice	2022-06-14 14:27:49			192.168.10.11	Time Sync	Time signal from ntp1 is out of tolerance (3 secs, max: 2 secs)	Dismiss
803	Daemon	Notice	2022-06-14 15:22:21	admin	192.168.1.1	192.168.10.11	Restore	User refused the restore	Dismiss
805	Daemon	Notice	2022-06-14 15:29:54	admin	192.168.1.1	192.168.10.11	Restore	Restore failed, this is not a backup file!	Dismiss
812	User	Notice	2022-06-15 06:43:42			192.168.10.11	Startup	Device started	Dismiss
856	User	Notice	2022-06-15 08:56:04			192.168.10.11	Startup	Device started	Dismiss
862	User	Notice	2022-06-15 09:43:42			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1	Dismiss
874	User	Notice	2022-06-15 10:51:06			192.168.10.11	Startup	Device started	Dismiss
878	User	Notice	2022-06-15 11:01:44			192.168.10.11	Startup	Device started	Dismiss
891	User	Notice	2022-06-15 11:40:47			192.168.10.11	Startup	Device started	Dismiss
897	Daemon	Notice	2022-06-15 11:48:42	admin	192.168.4.166	192.168.10.11	Epcs Upload	Epcs error: Unsupported config file version: 2.10.1. Supported version is: 2.10.2	Dismiss
900	User	Notice	2022-06-15 11:53:56			192.168.10.11	Startup	Device started	Dismiss
909	User	Notice	2022-06-15 12:08:45			192.168.10.11	Startup	Device started	Dismiss
934	User	Notice	2022-06-15 15:29:24			192.168.10.11	Startup	Device started	Dismiss

Figure 4-25 A sample entries list

**Syslog level settings** – Alarm entry logs can be classified according to facility and severity. The facility defines the entity in the device which is responsible for the specific alarm. For example, a user is probably a client from a PC, a daemon is the device CPU itself, etc.

The screenshot shows the 'Syslog Level Settings' interface. The left sidebar is the same as in Figure 4-25, with 'Alarms / Logging' selected. The main area shows a table of settings for various activities, with columns for Activity, Facility, Severity, and Edit.

Activity	Facility	Severity	Edit
Login	Auth	Notice	Edit
Logout	Auth	Notice	Edit
Upload	Auth	Notice	Edit
Settings	User	Notice	Edit
Parameters	User	Notice	Edit
Options	User	Notice	Edit
User Manager	User	Notice	Edit
Role Manager	User	Notice	Edit
Pfw Upload	Daemon	Notice	Edit
Psp Upload	Daemon	Notice	Edit
Epcs Upload	Daemon	Notice	Edit
Restore	Daemon	Notice	Edit
Command	Daemon	Notice	Edit
Download	Daemon	Notice	Edit
Audit	User	Notice	Edit
Time Sync	User	Notice	Edit
Startup	User	Notice	Edit
Card	Daemon	Notice	Edit
IO Simulator	User	Notice	Edit
Nameplate	User	Notice	Edit

Figure 4-26 Syslog level settings from the alarms / logging menu

### 4.2.10.5 Audit trails

An audit trail is a log of activities meant to log different entries that monitor the usage of the device. These activities are stored in a non-erasable database in the device.

The screenshot shows a web interface titled "Audit Trails" with a sidebar menu on the left. The main area displays a table of log entries with columns: Id, Facility, Severity, Time, User, Source, Destination, Activity, and Details. The table contains 17 entries, including logins, uploads, time syncs, and parameter changes.

Id	Facility	Severity	Time	User	Source	Destination	Activity	Details
1330	Auth	Notice	2022-09-01 11:33:53	admin	192.168.4.113	192.168.10.11	Login	success
1331	Auth	Notice	2022-09-01 11:34:03	admin	192.168.4.113	192.168.10.11	Upload	filename: 'E2-Line_F_polediscrepancy.epcs'
1332	Daemon	Notice	2022-09-01 11:34:52	admin	192.168.4.113	192.168.10.11	Epcs Upload	Configuration updated successfully. Restarting device.
1333	User	Notice	2022-09-01 11:36:33			192.168.10.11	Startup	Device started
1334	User	Notice	2022-09-01 11:37:07			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1
1335	Auth	Notice	2022-09-01 12:17:35	admin	192.168.4.113	192.168.10.11	Login	success
1336	User	Notice	2022-09-01 12:17:56	admin	192.168.4.113	192.168.10.11	Parameters	Parameter change is initiated from Web, no confirmation required
1337	User	Notice	2022-09-01 12:34:35	admin	192.168.4.113	192.168.10.11	Parameters	Parameter change is initiated from Web, no confirmation required
1338	Auth	Notice	2022-09-01 16:32:37	admin	192.168.4.113	192.168.10.11	Logout	session timeout
1339	User	Notice	2022-09-02 08:02:50			192.168.10.11	Startup	Device started
1340	User	Notice	2022-09-02 08:03:17			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1
1341	User	Notice	2022-09-02 16:25:07			192.168.10.11	Time Sync	NTP1 sync lost with server 192.168.1.1
1342	User	Notice	2022-09-02 16:28:39			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1
1343	User	Notice	2022-09-05 06:25:46			192.168.10.11	Startup	Device started
1344	User	Notice	2022-09-05 06:26:12			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1
1345	User	Notice	2022-09-05 14:18:41			192.168.10.11	Startup	Device started
1346	User	Notice	2022-09-05 14:19:08			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1
1347	Auth	Notice	2022-09-05 16:17:34	admin	192.168.4.213	192.168.10.11	Login	success
1348	Auth	Notice	2022-09-05 16:18:37	admin	192.168.4.213	192.168.10.11	Upload	filename: 'E2-Line_F_4chtest.epcs'
1349	Daemon	Notice	2022-09-05 16:18:57	admin	192.168.4.213	192.168.10.11	Epcs Upload	Epcs error: Unsupported config file version: 2.10.1. Supported version is: 2.10.2
1350	User	Notice	2022-09-05 16:34:54	admin	192.168.4.213	192.168.10.11	Parameters	Parameter change is initiated from Web, no confirmation required
1351	User	Notice	2022-09-05 16:36:16	admin	192.168.4.213	192.168.10.11	Settings	System settings change is initiated from Web, no confirmation required
1352	User	Notice	2022-09-05 16:38:13			192.168.10.11	Startup	Device started
1353	User	Notice	2022-09-05 16:38:40			192.168.10.11	Time Sync	NTP1 sync restored with server 192.168.1.1

Figure 4-27 A sample audit trail entry list



**NOTE:** This is not a setting menu, but a reference point for auditors to assess whether the device is being used in the right manner.

## 4.2.11 Advanced

The advanced menu contains three items: **Maintenance**, **I/O tester**, and **Update manager**.

### 4.2.11.1 Maintenance

The following fields are found on the maintenance menu:

In the **Cards** field (Figure 4-28), it is shown how the hardware of the device matches the hardware layout defined in its configuration (created in EuroCAP → Rack Designer). In case of any mismatch, the device stops operating and goes to Error mode (Status LED turns red)

This field provides more detailed information about the hardware.

There are three rules for matching the configured and the actual hardware in the devices:

1. *These types of modules must match entirely:*
  - **ATO+** modules (analogue outputs)
  - **COM+** modules (communication modules for busbar and line diff. protections)
  - **CT+** modules (CT inputs)
  - **INJ+** modules (for DRL arc suppression coil controller)
  - **RAI+** modules (rotor earth fault injector/measurement)
  - **VT+** modules (VT inputs)
2. *For all other modules, those of the same type (see highlighted as **bold** below) can be interchanged. Here are some examples:*
  - **O12+**/2201 ↔ **O12+**/1101 (and all other **O12+** modules)
  - **CPU+**/1201 ↔ **CPU+**/1501 (and all other **CPU+** modules)
  - **PS+**/4201 ↔ **PS+**/2301 (and all other **PS+** modules)
  - **PSTP+**/2101 ↔ **PSTP+**/4201 (and all other **PSTP+** modules)
3. *Special cases that are not covered by the previous two rules:*
  - **HMI+** and **HMIT+** modules (remote HMI) are also interchangeable
  - If a module can be equipped with different connector types (e.g. **VT+/2211** and **VT+/2211F** and **VT+/2211T**), these also can be interchanged.

Slot	Configured	Detected	Serial Nr.	Status
V	CPU+/1291	CPU+/1201	21125400	compatible
T(1)	CT+/5151	CT+/5151	13102503	matched
S(2)	CT+/5151	CT+/5151	21104897	matched
R(3)	VT+/2211	VT+/2211	17118684	matched
O(5)	TRIP+/2201	TRIP+/2201	17119265	matched
N(6)	TRIP+/2201	TRIP+/2201	10025264	matched
L(8)	R8+/00	R8+/00	20125736	matched
J(10)	COM+/9901	COM+/9901	18117093	matched
G(13)	O12+/2201	O12+/2201	12000299	matched
A(19)	PS+/2301	PS+/2301	11013695	matched
HMI	HMI+/3502	HMI+/3502	20132972	matched
BUS	BUS+/8401			passive bus

Figure 4-28 Card info field

**Device nameplate** (Figure 4-29) contains product information and basic data of the device.

PLATFORM:	IED-EP+
TYPE:	DTIVA
CONFIG:	E2-DTIF
ORD.CODE:	B4401301101-B120000000100401-4D
U aux PS:	90-300VDC,80-255VAC
In, Un:	200/100V
U aux BI:	220V
SERIAL No:	140739
Firmware ver.:	2.8

Made in Hungary

Figure 4-29 Device nameplate

In **LOG files** field (Figure 4-30) internal information about the specific part of the device (RDSP, system, LCD, etc.) can be found.




Figure 4-30 LOG files field

Serious errors (red status LED) and warnings (yellow status LED) are listed in the **Warnings and Errors** field (Figure 4-31). In the example below, time synchronization error is generated when time synchronizaton is lost with the timesync setting checkbox ticked from the **system settings-> Time synchronization** tab. For more information please refer to the [Troubleshooting guide](#).




Figure 4-31 Warnings and Errors

In case of any error, it is recommended to generate a system state report file (Figure 4-32) using the button in the **Backup / Report** field and send it to the [support team](#). The file has .prf extension and includes various crucial device logs, current configuration, currently set parameters and other parameter sets, current system and security settings, and current licences. However, it does not include disturbance records. Oscillographic fault records can be downloaded as illustrated in paragraph 4.2.6.



Make sure to check the size of the downloaded .prf file: it should be above 10 kB. If it is below this, try to download it again with a different or an updated browser.




Figure 4-32 Button for downloading the system state report (.prf) file

**Communication files** (Figure 4-33) for various protocols can be downloaded by clicking the appropriate button.




Figure 4-33 Communication files

The status of the ports of the internal switch are displayed in the **Ethernet links** field (Figure 4-34).




Figure 4-34 Ethernet link info

The PRP/HSR Status and Test field appears on devices equipped with a PRP/HSR CPU module. The communication status and test mode are set here.




Figure 4-35 PRP/HSR (if exists) status and test

The memory info field (**Device housekeeping**) in Figure 4-36 provides information about the CDSP resources.




Figure 4-36 Memory info

The **Time synchronization** field (Figure 4-37) shows information about time synchronization supervision. In EP+ devices, time synchronization signal can be obtained from a variety of sources. Both GPS-based, ethernet-based, serial-based or a combination of any can be set. Depending on what hardware modules are available in the device, the following time synchronization protocols can be set: IRIG-B, PPS, PPM, Protecta Legacy, PTP, NTP, IEC101, IEC104, DNP3, MODBUS & ABB\_SPA.

If no external source is available and set, the time in the device can be synchronized manually from the PC time settings using the “set device” button.




Figure 4-37 Time synchronization info

#### 4.2.11.2 I/O tester

The web page for advanced functions provides I/O simulation.

**Front panel LED test** - by clicking on this button the front LEDs will be tested with a blink sequence.

**Simulate binary inputs** - by enabling this function user can simulate the inputs. For safety reasons, enabling this function must be confirmed on the LCD screen on the device. The LED symbol between the SET and RESET buttons shows the current state of the input: red if activated, green if inactive. Simulation mode can be disabled with the button on top of the input control buttons. While the simulator mode is active, the Status LED of the device is yellow.



**CAUTION:** The device is still fully functional in this mode, meaning that it can still generate trip signals!






Figure 4-38 Input simulator mode






**Direct control of the output contacts** - prior to use this function the device should be switched to “Test/Blocked” mode in the **Commands** menu.




**Figure 4-39 Direct control of the output contacts (other modes)**

In “Test/Blocked” device operation mode, all the functions of the device (i.e. protections, measurements, control functions etc.) are blocked from controlling the binary outputs. Once the mode is changed, the option to request direct control of the output contacts appears.



**Figure 4-40 Direct control of the output contacts (test/blocked mode)**

Clicking on “Request” prompts a confirmation on the LCD screen. Upon confirmation, the output contacts can be controlled directly by the user. The LED symbol between the “Set” and “Reset” buttons shows the current state of the output: red if activated, green if inactive. To disable this function, change the Mode of the device to “On” state in the **Commands** menu.



**Figure 4-41 Output simulator mode**

### 4.2.11.3 Update manager

The **Version info** field displays the EuroProt+ system version and the current firmware version in the device.




Figure 4-42 Version info window

In the **Restore** field the user can upload configuration and parameter settings from a system state report (.prf) file into the device.




Figure 4-43 Restore tab

Device firmware can be upgraded when a new version is available. This can be done from the **Firmware** tab. More detailed information about the current firmware is available in the text field (Figure 4-44).




Figure 4-44 Update firmware tab

To update, click on the “Update firmware” button, select the appropriate file and click OK. A dialog on the LCD will ask you to confirm updating. Detailed information about the latest firmware updates can be found on the Protecta website in the [release and revision history](#) (login required). If new firmware update is needed, please contact Protecta [support team](#).

All digital outputs (relay contacts, trip contacts) must be disconnected from the protected object(s) before commencing firmware update.



**CAUTION:** Never load an older version of the firmware to the device! Firmware update must always be done with care, because mistakes in this process may cause devices malfunction. It is advisable to get the system state report of the device (.prf file) before commencing the update. This way the device can be restored in case anything goes wrong.



**IMPORTANT:** Before any firmware upgrade, the LCD will display a SHA-256 digest in form of a unique code. This code is used to verify whether the firmware file being uploaded is legitimate. The reference can be obtained from firmware release notes or by contacting the Protecta Application department. For a legitimate upgrade, the SHA-256 code displayed on the screen should match with the code provided in the release notes for the specific firmware. In Figure 4-45 below, 614b961a3b77 is the SHA-256 digest for firmware version 3010-H3.




Figure 4-45 Firmware name and its SHA-256 digest for new firmware upon upgrade

In the **Configuration** field, the user can download the configuration file (.epcs) from the device. Here, a digitally signed configuration file (.epcs) can also be uploaded to the device, depending on the privileges of the user.




Figure 4-46 Configuration tab for a user with "manage configuration" rights



Once again, it is advisable to download the system state report (.prf) file before commencing a configuration update from a previously active device. This is again to ensure that in case of any malfunction due to a configuration update, the device can be restored.

The **Manufacturer Settings** tab can be used to view and manage the PSP file. A PSP (Protecta Settings Package) is a file provided by the manufacturer to the device owner, containing various licences and functionality level of the CPU.

The first PSP file is determined and loaded in the factory based on the ordering info of the device. If a future upgrade is required, the manufacturer may send another PSP file to the customer in due course, to cover for licence upgrades, feature software upgrades or functionality level upgrades.



**NOTE:** The PSP file cannot be downloaded, as it is device specific. Downloading implies that it can be uploaded to other devices, which should have their own PSP file from the manufacturer.




Figure 4-47 The "Manufacturer Settings" tab showing the enabled licenses & CPU functionality level from the current PSP file

## 5 Troubleshooting

This section helps the user to evaluate warnings and errors experienced during device operation. If further support is required, please contact Protecta through the [web support tool](#) with detailed error description and all the information described in paragraph 5.2.

### 5.1 Warning and Error Messages

Inappropriate or faulty conditions cause the device to give warning or error messages which can be seen in the **Advanced** -> **Maintenance** -> **Warnings and Errors** tab. In some cases, the warning/error message can also be seen on the local display of the device.

#### 5.1.1 Warning messages in the web browser

In case of warnings the status LED would usually turn yellow. Any exceptions are shown in the table below. A warning sign (yellow triangle) also appears below the menu bar on the web interface. In this case, depending on the error, several functions can be paralysed. The possible messages are listed in the table below.




Figure 5-1 Warning messages in the web browser

The following tables summarize the warning messages.

Table 5-1 RDSP Runtime warning messages

WARNING MESSAGE (RDSP RUNTIME)	EXPLANATION
0x0001 (noPSAD)	PS modules with auxiliary voltage measurement do not transmit the measured value to the CPU properly. Suspected HW error.
0x0002 (vlanMismatch)	In line protection and binary signal exchange applications the VLAN settings are inconsistent. Consistency check recommended.
0x0004 extRtcCalibMode	CPU Real Time Clock accuracy is out of the tolerance range. Internal device clock won't work accurately, while the device is switched off. Suspected HW error.
0x0010 psVoltUnstab	The device internal power supply voltage (+/-12V) is unstable on the CT/VT module. Possible power supply or backplane failure.
0x0400 siliconRevMismatch	The RDSP firmware and the CPU chip hardware versions are different.
0x8000 adControlWarn	AD converter failure on an analogue input module. The faulty module can be determined from the RDSP log, which can be opened from the <b>Advanced</b> -> <b>Maintenance</b> -> <b>LOG files</b> tab. Suspected HW error.

Table 5-2 CDSP warning messages

WARNING MESSAGE (CDSP)	EXPLANATION
0x0001 (System)	System level warning (e.g.: Parallel DRL message version discrepancy)
0x0002 (Config)	Configuration inconsistency or structural problem. The system is still operating.
0x0004 (Param)	Parameter problem, such as: <ul style="list-style-type: none"> <li>- during startup the device is unable to determine the number of parameter sets</li> <li>- parallel DRL addressing warning (same master and slave address used)</li> </ul>
0x0008 (LCD application)	System level warning, which is hampering LCD startup. It may happen when the device is building up communication between the RDSP and the CDSP via the high-speed bus application (sport).
0x0040 (Time synchronization)	Time synchronization warning. Check the <b>Time synchronization</b> settings in the <b>System settings</b> menu and verify the signal source.
0x0100 (RDSP comm. error)	RDSP communication problem. Software inconsistency or hardware error possible.

Table 5-3 Application warning messages

WARNING MESSAGE (APPLICATION)	EXPLANATION
0x0001 (diff3wVgroup)	The connection of the primary winding in primary-secondary and primary-tertiary relation is selected in contradiction (eg. Y and D) in the Transformer Differential protection function block. The function is disabled in this situation.
0x0002 (rangeMismatch)	This error typically occurs when a protection function works with two or more quantities that must be on the same secondary basis.  Example: For <i>SumCT</i> function block, the IED needs to perform addition of currents coming from two or more CTs. If the secondary rating parameter of one current input module is set to 5A while the other is set to 1A, the IED generates this warning. Indicated with red LED.
0x0004 (nompeakMismatch)	Example: Summed currents used in certain function blocks are measured by different types of CT modules, for which the max. measured current is different (e.g.: CT+5151 module 50x In, CT+5101 module 4. channel 12,5x In).
0x0008 (frSourceMissing)	Frequency based function blocks are used in the configuration but no frequency source is configured.
0x0010 (modeNotOn)	The mode of device according to IEC 61850 is not "On". It can be switched to "On" in the <b>Commands -&gt; Common</b> field.
0x0020 (userUKE)	The 'External Warning' binary status input signal of the Common function block is TRUE. This is defined by the user in the graphical logic editor. Possible reasons are status feedback failure, VT MCB failure, etc...
0x0040 (mvDistVolt)	The 'Connection U1-3' parameter of the <b>VT4 module</b> function block is set to Ph-Ph while the 'Operation' parameter of any distance protection or directional overcurrent function block is not Off. These functions are disabled in this situation.
0x0080 (eventRecSize)	The number of the configured events channels has reached the limit.
0x0100 (simulatorMode)	Binary input simulator mode enabled.
0x0200 (wrongSysFrv)	The set 'Power system frequency' from <b>System settings -&gt; System parameters</b> tab and the frequency of the measured voltage are different. 50Hz measured and 60Hz set or vice versa.
0x0400 (maxILoadHigh)	The 'Max.I_load' parameter of the Busbar differential protection is set higher than the "Base sensitivity" of the differential characteristics.
0x0800 (genParamError)	Other parameter mismatch. (E.g set value is out of range after a firmware upgrade). For more details see the RDSP log.

WARNING MESSAGE (APPLICATION)	EXPLANATION
0x00010000 (Analogue connection warning)	Either of the analogue inputs of a function block with graphical analogue inputs is not connected on the EuroCAP logic editor. To fix, make sure all the required analogue inputs of function blocks are connected.
0x00020000 (Analogue range parameter missing)	Parameter assignment to analogue inputs not complete in the configuration. Error can only be fixed by contacting <a href="#">Protecta Support</a> .
0x00040000 (Analogue channel preprocessing not initialized)	Incorrect relay task execution order. Relay task execution order should be optimized in order to properly initialize functions with analogue inputs. Please contact Protecta Support to fix the problem.

## 5.1.2 Error messages in the web browser

In case of errors the status LED turns red. If the web page is accessible, a red STOP sign can be seen below the menu bar. When an error occurs, the Fault Relay NO contact opens as well. The device is unable to operate in this state. The error messages inform the user about the hardware errors.




Figure 5-2 Error message in the web browser

The following tables summarize the error messages.

Table 5-4 RDSP Runtime error messages

ERROR MESSAGE (RDSP RUNTIME)	EXPLANATION
0x0004 (moduleNotAvailable)	The CPU does not detect a module during operation. Suspected HW error.
0x0008 (flashError)	Suspected HW error.
0x0010 (pldSelfCheckFailed)	Connection failure between the RDSP and the backplane communication logic. Suspected HW error.
0x0020 (relayStoppedByFwConfigUpdate)	The device has not restarted automatically after a configuration or firmware download. Repeat the download procedure.
0x0040 (singleModuleADErr)	Double AD control failure: One analogue input module is affected, which can be determined from the RDSP log based on the card serial number.
0x0080 (multiModuleADErr)	Double AD control failure: Multiple analogue input modules are affected, which can be determined from the RDSP log based on the card serial numbers.
0x0100 (allModuleADErr)	All analogue input modules are failed. Suspected power supply module or backplane failure.
0x0800 (paramLoadingFailed)	After "Set parameters" command the RDSP dataflash content is invalid. Repeat parameter setting.
0x1000 (psSecondaryVoltFailed)	Power supply internal voltage (+/-15VDC, +12VDC or 3,3VDC) is out of the specified limits.
0x4000 (psVoltFailed)	Power supply module with auxiliary voltage monitoring function detects voltage out of the limits. Check the auxiliary voltage.
0x8000 (adControlErr)	There is an error occurred in one/some of the analog input modules (e.g.: CT, VT, AIC, RTD). Replacement of the faulty module required.



Table 5-5 RDSP Init error messages

ERROR MESSAGE (RDSP INIT)	EXPLANATION
0x0001 (hwPostError)	HW test during device start-up has detected a failure. See the RDSP log for more details.
0x0002 (configError)	Configuration download from the data flash was not successful. Reload the configuration.
0x0004 (paramError)	Parameter download from the data flash was not successful. Reload parameter set.
0x0008 (anaCorrFailed)	It was not successful to load all the analogue channel corrections from the analogue input module. Possible failure of the analogue module, CPU or backplane.
0x0010 (cardConfMismatch)	Mismatch between the detected and configured modules. More details can be found in <b>Advanced</b> -> <b>Maintenance</b> -> <b>Cards</b> tab.
0x0020 (failed2LoadVars)	Reloading the configuration will rectify the problem, if there is no HW error.
0x0080 (failedNonvolVarFormat)	Suspected HW error.
0x0200 (noValidPSCard)	Unable to detect Power Supply module. Possible failure of the power supply module, CPU or backplane.
0x0800 (fwConfMismatch)	RDSP firmware does not fulfill the configuration version requirement. Certain function blocks used in the configuration are not implemented in the RDSP firmware, therefore a firmware update is recommended.
0x1000 (noClearForcedModeStat)	For R&D purposes only.
0x2000 (funcLevelMismatch)	The function level of the CPU is lower than that of the downloaded configuration file. Configuration file or CPU module level modification shall be executed by Protecta staff.

Table 5-6 CDSP error messages

ERROR MESSAGE (CDSP)	EXPLANATION
0x0001 (System)	Critical system error. Corrupted file or hardware error possible. The system cannot operate reliably.
0x0002 (Config)	Critical configuration error, inconsistency or internal structural problem. The system cannot operate reliably.
0x0004 (Param)	Critical parameter error or data inconsistency on the CDSP or RDSP.
0x0020 (TCP communication)	TCP communication system error. Hardware or other system error possible.
0x0080 (File I/O)	File system error. The device cannot generate the RDSP log.
0x0100 (RDSP comm. error)	RDSP communication problem. Software inconsistency or hardware error possible.

Table 5-7 Hardware Init error messages

ERROR MESSAGE (HW INIT)	EXPLANATION
0x0004 (FRAMError)	FRAM failure indicating CPU HW error.
0x0008 (extRTCError)	Real Time Clock reset generator failure indicating CPU HW error.
0x0010 (sramError)	SRAM test failed at power up indicating CPU HW error.
0x0020 (codeFlashError)	Flash IC no. 13 failed on the CPU module indicating CPU HW error.
0x0040 (dataFlashError)	Flash IC no. 14 failed on the CPU module indicating CPU HW error.
0x0080 (sdramError)	SDRAM test failed indicating CPU HW error.
0x0100 (xilinxInitError)	CPU HW error caused by the Xilinx.
0x1000 (pldSRAMMagicStrFillFailed)	If the IED started with power supply off/on switching, it tries to write a control data string in the SDRAM. If this operation fails, the error message appears indicating the CPU HW error.
0x2000 (pldSelfCheckFailed)	Self-check function detected a failure. Suspected CPU HW error.

### 5.1.3 Error messages on the LCD screen

If there is a fault while uploading a configuration to the device or updating the firmware, the device enters the emergency mode, which also means that it is unable to operate. The following error messages may appear on the LCD screen if an unsuitable firmware has been loaded to the device (e.g. lower than the minimum required by the configuration).




Figure 5-3 Error messages on the LCD screen

If this happens, the web page of the device will be different (see Figure 5-4), but the system state report file can still be downloaded by using the *Get report file* button on it. This file is important for troubleshooting for the Protecta Support team, as it contains all necessary information about the device (configuration file, all the logfiles, parameters, settings, licences, etc.).

In these cases please contact Protecta Support on the [web-based support system](#).



The screenshot below shows the device in emergency mode with all the log files and the system state report download button.

In the **Log and Report files** tab, the user can download the system state report from the device. Other types of log files can also be downloaded by clicking on the respective link within the tab.

The primary way of restoring a device from emergency mode is by uploading a backup or system state report file (.prf) from the last known working state of the device. This is done from the **Restore device** tab.



**NOTE:** It is highly likely that a .prf file downloaded from a device in emergency mode cannot restore a device. This is why it is recommended that before any upgrade, a system state report file should be downloaded. This way, if the device enters emergency mode, a .prf file from a working system can be uploaded.

Other ways of restoring a device may involve uploading a firmware (.pfw), configuration (.epcs) or manufacturer settings (.psp) file. This is done from **Firmware update** tab.

Prior to entering emergency mode, if the device had role-based access control activated, restoration will require authentication from the **Authenticate with user and password** tab. See Figure 5-4 below.

← → ↻ ⚠ Not secure | 192.168.80.4 🔍 🏠 ☆ 📄 🌐 ⋮

## Oops!

### The device is in emergency mode

Something bad happened with this device. Possible reasons could be unsupported configuration or wrong firmware version. You can study the available log files below or make an emergency report file for your support team.

We are sorry for the inconvenience.

**Authenticate with user and password**

Give user and password here if authentication is required.

User  Password

**LOG and Report files**

Build and download system state report.

[U-boot messages](#)  
[System messages](#)  
[Relay log](#)  
[SPORT log](#)  
[LCD log](#)  
[Serial log](#)  
[IEC61850 log](#)  
[PMU log](#)  
[Httpd error log](#)  
[Additional info](#)  
[Overall info](#)

**Restore device**

Restore the device from backup file  No file chosen

**Firmware update**

Firmware update  No file chosen

EPCS Upload  No file chosen

PSP Upload  No file chosen

**Process Log**

Click [here](#) to expand.

Figure 5-4 Web page of a device in emergency mode

### 5.1.4 Operation of the IFR (Internal Fault Relay)

A de-energized fault relay indicates an error in the following three scenarios:

- The device is switched off or it is starting up (while the Status LED is red)
- Errors (red Status LED)
- The ExtWarning input of the Common function block is active (user-defined warning)

In any other case (normal operation, or other, non-user-defined warnings that cause a yellow status LED), the fault relay is energized.

## 5.2 Necessary data before contacting Protecta Support

Sending the system state report file is the preferred method in order to provide all important information to the support team. If the file cannot be downloaded for some reasons, the data below have to be provided when contacting us, so the device can be identified quickly:

- Serial No. of the device
- Firmware version
- Configuration name and date

### 5.2.1 Serial Number of the Device

The device serial number can be found on the Device Nameplate which is located on the upper right side of the device, close to the backplane.



Figure 5-5 The device name plate

There are cases when the physical Nameplate cannot be accessed because of the location of the device. In these cases, connect to the IED on its Service Port, and open its web page. Here the serial number can be found on the virtual nameplate located in the **Advanced -> Maintenance -> Device nameplate** tab.





Figure 5-6 The device virtual nameplate

## 5.2.2 Information about firmware and configuration versions

The firmware and configuration versions can be shown on the second page of the device home screen, which can be accessed by touching the info  icon.




Figure 5-7 Firmware (Revision) and configuration information on the LCD

If the local screen cannot be accessed, the web page can also be used to obtain the **Version info** from **Advanced -> Update manager** menu.




Figure 5-8 Firmware and configuration information on the web

### 5.3 Quick Troubleshooting

The table below contains the typical faults and errors that may occur during commissioning or operating the device with possible reasons and solutions. If necessary, please contact the [Protecta Support Team](#):

Table 5-8 Typical errors

STATUS LED	LCD DISPLAY STATUS	FRONT PANEL BUTTONS	POSSIBLE FAULT	SUGGESTION
Dark	Dark	Do not react on touch.	a. No supply voltage. b. Supply voltage is out of range. c. Power supply module failure	Check the supply voltage and the LED on the power supply module.
Green	Dark	Do not react on touch.	a. LCD display failure b. In cases of CDSP version lower than 2.8.13.912 it is possible that the LCD screen froze.	In case of reason b., a CDSP firmware upgrade will fix the issue.
Green	Works but the time shown is wrong.	Working.	No time synchronization signal is received (or it is not received regularly enough). This way the time can go out of sync.	Use the Set device time button on the web page located in the <b>Advanced-&gt;Maintenance</b> menu. This will set the time in the computer operating system to the device.
Yellow	Working.	Working.	There is an external time synchronization device connected and the "Timesync warning" parameter is set in the system parameters menu, but no synchronization signal is received. In this case on the web page in the <b>Advanced -&gt; Maintenance -&gt; Warnings and Errors</b> tab, a warning message can be seen (0x0040 Time sync warning)	Check the settings and connections of the time synchronization device

STATUS LED	LCD DISPLAY STATUS	FRONT PANEL BUTTONS	POSSIBLE FAULT	SUGGESTION
Yellow	Working.	Working.	In the user logic there is a signal connected to the "ExtWarning" input of the Common function block, and this signal is TRUE. This will also be indicated by the Failure Relay and on the web page in the <b>Advanced-&gt; Maintenance -&gt; Warnings and Errors</b> tab, a warning message can be seen (0x0020 User warning)	Check the configuration of the device using the EuroCAP tool. Look for the Common function block in the graphic editor and see what kind of signal is connected to the ExtWarning input. The most common signals may be switchgear status signal errors or VT fuse errors etc.
Red	Working	Do not react on touch	a. a HW module is faulty b. the actual HW configuration is different than the one defined in the configuration	See if there are any issues with the HW modules. These can be checked on the web page in the <b>Advanced -&gt; Maintenance -&gt; Cards</b> tab. Contact Protecta personnel using the <a href="#">web-based support system</a> .